

Model	Bosch Aftermarket #	Bosch Part #	Alternative Bosch part #	Notes
6.0L XJ-S	13313	0258003313	0258003084 0258003309 0258003957	Probably no cost savings - these are all exotic cars
All 3-wire	13032	0258003032	0258003031 0258003931 0258003060 0258003006 0258003680	Have the same connectors but a longer harness
			0258003006 0258003013 0258003021 0258003025 0258003031 0258003032 0235003046 0258003051 0258003060 0258003074 0258003078 0258003086 0258003087 0258003090 0258003093 0258003102 0258003106 0258003165 0258003166 0258003182 0258003190 0258003203 0258003204 0258003211 0258003212 0258003229 0258003239 0258003243 0258003292 0258003320 0258003321 0258003324 0258003373 0258003513 0258003514 0258003716 0258003717 0258003719 0258003913 0258003915 0258003925 0258003931 0258003942 0258003950 0258003953	Have the correct sensor body but the connector will have to be spliced in. O2 sensor splices should be air/water tight
1-wire sensor	11051	0258001051	0258005725 0258001026 0258001052 F00HL91041 F00HL91051 F00HL91052	Universal Sensor These are all drop in replacements.